

WOODEN CAMERA



UNIVERSAL BASEPLATE



1

Gather Phillips screwdriver, SAE allen set and included components.

2

Select appropriate length rods and attach (4) 1/4-20 screws.



3

Choose correct screws for camera base.

4

Tighten screws to camera body.



5

Slide base unit onto camera.

6

Adjust to correct lens height and tighten (2) #8 screws.



7

Keep rods and screws in secure location for future use.

