

WOODEN CAMERA



EASY TOP / EASY TOP X



1

Gather camera, Torx, Metric, and SAE allen set, and included components.

2

Use T9 Torx wrench to remove (4) screws from top of camera.



3

Remove plastic vent cover and set aside.



4

Install (2) 1/4-20 socket cap screws in corresponding holes.



5

Install (4) M4 button head screws in corresponding holes.



6

Keep plastic vent cover and screws in secure location for future use.