

WOODEN CAMERA



- 1 Gather Phillips screw driver and included components.



- 3 Discard cardboard and metal back plate.



- 5 Install (4) included M3 screws.

QUICK BACK v2 (GOLD MOUNT)



- 2 Detach Gold Mount plate from backing pieces.



- 4 Align battery plate on Quick Back v2.



- 6 Snap Quick Back v2 assembly onto back of camera and attach LEMO to camera power port.