

WOODEN CAMERA



1

Gather Metric allen set, Phillips screwdriver, and included components.



3

Discard cardboard and metal back plate.



5

Align battery plate on Fixed Back.



7

Attach LEMO to camera power port.

FIXED BACK (GOLD MOUNT)



2

Detach Gold Mount plate from backing pieces.



4

Attach Fixed Back to camera rear using (4) M4 socket cap screws.



6

Install (4) included M3 screws.