

GLIDECAM IGLIDE ADAPTER



Glidecam iGlide Adapter shown attached to a Glidecam iGlide

GLIDECAM IGLIDE ADAPTER

The lightweight and state-of-the-art Glidecam iGlide™ Adapter is designed specifically for the Apple iPhone 3G, 4G, 4S and 5, allowing these "Smartphones" to be attached directly to the Glidecam iGlide and XR-1000 Hand-Held Camera Stabilizers, transforming 'Smartphone' video into hypnotically smooth, professional footage, for publishing directly to the Worldwide Web.

With the Glidecam iGlide Adapter attached to your Glidecam iGlide or Glidecam XR-1000 hand-held Stabilizer your Smartphone seems to float, always balanced, isolated from your hands undesirable motions. Now you are free to move - panning, tilting, booming or running without any cell phone camera instability or shake.

With the Glidecam iGlide Adapter attached to your Glidecam iGlide or Glidecam XR-1000 they work so well that they allow you to shoot incredibly smooth and graceful shots even while going to extremes like running up and down stairs or traveling over rugged terrain. And when it comes to walking or moving slowly around someone, the results are equally magical.





Glidecam iGlide Adapter shown attached to the Camera Plate of a Glidecam iGlide (Back View)





Glidecam iGlide Adapter shown attached to the Camera Plate of a Glidecam iGlide (Front View)

Glidecam Industries, now becoming the choice of a generation. Glidecam makes your decisions concerning camera stability and movement, simple and easy. When you wish for your camera to glide smoothly along your chosen path, simply rely, as so many have and still do, on using a Glidecam Camera Stabilizer. Glidecam Industries, Inc., now in its nineteenth year, offers a wide range of camera stabilizers each optimized for various camera weights and shooting conditions.

