


IDMX500

500 LED DMX Studio Light QUICKSTART GUIDE



What's included

- ☐ IDMX 500 Light
- ☐ AC Adapter + Power Cord
- ☐ Yoke
- ☐ Handle (2)
- ☐ Stand Adapter

Checked by

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.

ikan

www.ikancorp.com

1.713.272.8822

support@ikancorp.com

© 2013 ikan Corporation. All right reserved

IDMX500

500 LED DMX Studio Light QUICKSTART GUIDE

GETTING STARTED

1. Connect the included AC Adapter to power the IDMX 500 light.
2. Turn the light on / off with the Power Switch.
3. Control the amount of the light with the Touch Screen. Adjust the intensity of the light by touching the up or down arrows to increase or decrease the intensity.
4. DMX Control can be used by 512 DMX Board.

