

## R CT 5020 - Rack Controller for Series 3000



### Key Features.

- Provides remote control, status monitoring and error reporting for all installed Series 3000 MiniModules in RFR 3010 or 3011 Rack Chassis
- Includes Windows based LYNX desktop controller software application
- RS 232 Serial interface to standard PC
- Interfaces to the R CT 5030 master controller for further system expansion possibilities
- Hot swappable

### Description

The R CT 5020 provides for the remote control, status monitoring and error reporting of all installed Series 3000 MiniModules in a single rack.

This controller can also be interfaced into the R RCT 5030 Master controller for further system expansion possibilities.

Provides a RS 232 serial interface to host PC. Supplied with the LYNX Desktop Controller Application (Windows 2000, XP, Vista, Win7)

**NOTE.** The RS 232 interface is a distance restricted and the PC with the LYNX desktop controller needs to be close enough for a 3M (max) cable reach. If this distance is restrictive then please use the RCT 5030 Master controller with uses a LAN interface.

### Options / Ordering Information

#### **Ordering Information**

#### **R CT 5020 - Rack Controller**

*Includes: Controller, control system Software package (CD) and user manual*

**Note:** Control System Software requires standard PC with Microsoft Windows 2000, XP, Vista, Win7 (not supplied)

#### **Options**

R CP 5000 - 1 RU Remote control panel

R CP 5016 - 1 RU expansion panel for the R CP 5000

Downloads



User Manual