# **16-FREQUENCIES**

# 1 CHANNEL-SYSTEM







**UHF WIRELESS MICROPHONE-SYSTEM** 





Mobile or fixed installation for:

- Exhibitions and Fairs
- Seminars and Schools
- Stage, Church and Sporting Events

# RC5

# 1 CHANNEL-SYSTEM / 16 FREQUENCIES





- **■** True-Diversity
- 16 Frequencies
- Suitable for Multi-Channel-Systems

The WR-016 receiver offers excellent HF- and NF-characteristics. Due to the integrated diversity-system we can look at best radio transmission results even in problematic environments. The receiver compares both of the antennas and its adjacent signals and selects the strong one.


The selection of the pre-programmed frequencies happens very comfortably via a Dip-switch.

- Hand- and Body pack-Transmitter are available as a transmitter
- Ability to choose between 16 frequencies in order to achieve trouble-free reception
- Room-saving 19" width for installation of 2 receivers next to each other
- The antennas are available to install in a distance.





iechnicai Data	UHF-Receiver
Frequency Range	794 – 813 MHz (16 frequencies)
Operating principles	Diversity
Signal-to-noise ratio	> 94 dB
Frequency response	50 Hz – 15 KHz
Distortion factor	< 1 %
Squelch	Pilottone & Noise lock
Audio-Output	XLR: MIC bal. MIC/LINE
	switchable, unbalanced
Antenna	TNC, removable
Power supply	12 V DC via power supply
Scope of supply	Receiver, power supply unit, Antenna, cable (jack)
Dimensions / Weight	L 210 mm x B 175mm x H 44.3 mm (H); ca. 1 kg



Multi-channel-systems can be assembled with accessory components. The splitter AS-200 (19″, 1 RU) manages up to 4 transmitters WR-016. The booster AB-200 provides sufficient amplification as an external cable driver.

External UHF-Antenna, (pair)	AN-200
UHF-Antenna-Booster, (pair)	AB-200
UHF-Antenna-Holder, (pair)	AH-200
UHF-Antenna-Splitter, 1 RU	AS-200
19"-Rack Assembly-Set, for front-assembly the antenna	<b>RU-203 T</b>

# 1 CHANNEL-SYSTEM / 16 FREQUENCIES



## **UHF-Wireless Hand Microphone**



#### Description

This UHF-Hand Microphone is equipped with a premium condenser microphone capsule. It is a very handy microphone. The frequencies can easily be adjusted via a comfortable Dipswitch. The power supply results from 2 Mignon-Batteries.

Technical Data	UHF-Hand Microphone
Carrier frequency	794 – 813 MHz (16 frequencies)
Modulation	FM
Transmission	PLL synth.
RF Output Power	10 mW
Frequency response	60 Hz – 15 kHz
Microphone type	Condenser microphone
Power supply	2 pcs Mignon (1,5V; AA)
Transmission range	approx. 50 m
Dimensions / Weight	Ø 50 mm x L 260 mm; 250 g

UHF-Hand Microphone, (16 Frequencies)......WH-016



Very comfortable condenser-neckworn-microphone conducted in the characteristic of a kidney. Due to the low deadweight and the flexible material this microphone fits all head shapes perfectly. Available in the colours "skin-colour" and "black".

Neckworn-Microphone, skin-color. HS-200 S Neckworn-Microphone, black HS-200 B

## **UHF-Bodypack-Transmitter**



C€0336①

3-pin MINI XLR

for LA-200 or HS-200S/B

### **Description**

Body pack-Transmitter with 16 eligible frequencies. The input sensitivity is changeable in order to be able to induct Mic- and Line signals. The power supply results from 2 Mignon-Batteries.

Technical Data	UHF-Transmitter
Carrier frequency	794 – 813 MHz (16 frequencies)
Modulation	FM
Transmission	PLL synth.
RF Output Power	10 mW
Frequency response	60 Hz – 15 kHz
Max. Deviation	± 48 kHz
Power supply	2 pcs. Mignon (1,5V; AA)
Transmission range	approx. 50 m
Dimensions / Weight	64 mm (W) x 97 mm (L) x 24 mm (D); 150 g

#### **Lavalier Microphone**



Condenser microphone completed in ball-characteristic. Delivery includes an 80 cm long connecting cable and a clip. It is available in the colour black.

Lavalier-Microphone, black .......................LA-200

# RC5

# **ACCESSORIES**

## **ACCESSORIES**

# 19"-Rackmount Set for one WR-016





19" brackets for one Receiver unit (1 RU).

Mounting-Set.... RU-201
1RU, for one WR-016

## 19"-Rack Assembly-Set

for front-assembly the antenna



19" brackets for front antenna at one Receiver unit.

### Mounting-Set RU-201 T

1RU, for one WR-016



Ant.-Holder.....AH-200

# 19"-Rackmount Set for two WR-016





19" brackets for two Receiver units (1 RU).

Mounting-Set....RU-202 1RU, for two WR-016

#### Adapter cable

for Bodypack Transmitter WB-016

MIC/Line adapter cable (1 m) for external signals, with Mini-XLR to 6.3 mm jack connector for WB-016 bodypack transmitter.

# Adapter cable ... AC-200 (Mic/Line)



Mic.-Holder.....MH-800 for wireless Handmicrophones

## **UHF-Antenna-Booster**



Ant.-Booster .... AB-200

50 ohms Antenna cabel, equipped with TNC-Connectors. To install the UHF antenna in a distance (in your order please declare the desired cable length).

Antenna cable, desired length ..... ACT-050/xx