

Wooden Camera 146400 Crossbar



www.PhotoCineShop.com

□

Crossbar with ARRI style rosettes on each end for handle attachments. 1/4-20 and 3/8-16 mounting holes on top for accessory mounting. 1/4" slotted center to attach to other accessories like Rod Clamps, Safety Dovetails, cheeseplates, and more.