

Top Handle (Rubber)



(//Cdn3.volusion.com/akmsw.skkga/v/vspfiles/photos

/154100-2.jpg?1465815975)

Top Handle (Rubber)

(//Cdn3.volusion.com/akmsw.skkga/v/vspfiles/photos/154100-2.jpg?1465815975)

DESCRIPTION

Bolts on for secure camera carrying. No slip rubber grip with 1/4-20 mounting points in front for accessory mounting.

Handle Adapter (</Product-p/169800.html>) can be added to attach the Top Handle to any two non-standard screw spacings up to 36mm apart center to center.

Handle Riser (</Product-p/169700.html>) can be added to raise the height of the Top Handle.

Includes:

(2) 1/4-20 x 1/2" screws

Video Review By Finner Knows Best (Http://www.youtube.com/watch?v=BFFuD2yCy4&feature=player_embedded)

SPECIFICATIONS:

Weight: 166g (0.4 lbs)

Dimensions: 142.3 x 48.3 x 68.6 mm (5.6 x 1.9 x 2.7 in)
