

Lens Support Adapter (FS7)



(//Cdn3.volusion.com

/akmsw.skkga/v/vspfiles/photos/196000-2.jpg?1466410165)

(//Cdn3.volusion.com/akmsw.skkga/v/vspfiles/photos/196000-2.jpg?1466410165)

Lens Support Adapter (FS7) is designed to attach to the **Top Plate (FS7)** (</Product-p/193900.html>) and clamp onto the **E-Mount To PL Mount Pro** (</Product-p/194000.html>) when attaching to Sony PXW-FS7 camera. This is perfect for previous customers who purchased the **E-Mount To PL Mount Pro (A7s)** (</Product-p/182400.html>) and are upgrading to FS7. Loosen the support ring thumbscrew to quickly remove the mount and install another adapter. We are working on additional E-Mount to Canon, Nikon, etc. that will be available in the near future and will integrate with this same ring support.

Features:

- Support ring capable of integrating with **Top Plate (FS7)** (</Product-p/193900.html>)

Includes:

(2) 1/4-20x1/2" socket cap screws

Weight: 90.7 g (0.2 lbs)

Dimensions: 101.6 x 25.4 x 127 mm (4 x 1 x 5 in)
