

D-Box (C300mkII, V-Mount)



(//Cdn3.volusion.com

/akmsw.skkga/v/vspfiles/photos/215800-2.jpg?1498749306)

D-Box (C 300mkII, V -Mount)

(//Cdn3.volusion.com/akmsw.skkga/v/vspfiles/photos/215800-2.jpg?1498749306)

D-Box (C300mkII, V-Mount) is a custom version of our popular D-Box that adds power distribution, standardized remote start/stop, and hot swap abilities for the Canon C300mkII. Two 12 inch (30cm) cables exit the power plate with one going to the 4pin LEMO compatible power plug and the other going to the Remote port. There is a LANC control board inside the D-Box which communicates with the camera and allows any ARRI standard start/stop trigger to be used with the 3pin Fischer port.

The bottom of the D-Box has (3) 1/4-20 holes which can attach directly to our **Rod Clamp (15mm LW)** (</Product-p/150200.html>), **Rod Clamp (15mm Studio)** (</Product-p/150300.html>), and **Rod Clamp (19mm)** (</Product-p/150400.html>). For an adjustable mount system, use the **Battery Slide** (</Product-p/156600.html>) or **Recorder Slide** (</Product-p/191100.html>) paired with the same Rod Clamps listed above.

Connectors used in this assembly are not manufactured by LEMO but are made to the same specifications and are LEMO compatible.

SPECIFICATIONS:

Weight: 534 grams (1.18 lbs)

Dimensions: 90 x 146 x 43mm (3.5 x 5.7 x 1.7 inches)

[\(/V/vspfiles/instruction-sheets/d-box-c300mkII-v-mount-instructions-215800.pdf\)](/V/vspfiles/instruction-sheets/d-box-c300mkII-v-mount-instructions-215800.pdf)
