


NOTE: POCKET CAGE assembly required. See POCKET CAGE assembly instructions.


INSTALLATION

 Locate and loosen SOCKET CAPS on CAGE ASSEMBLY with 3/16 allen wrench


2. Locate RED MARK on LENS MOUNT and MFT MOUNT




 Aligning both RED MARKS, fit LENS MOUNT to MFT MOUNT and gently twist clockwise to lock into place




- 4. Locate M4x20 HOLES on ADAPTER FOOT
- Using M3 allen wrench tighten M4x20 SOCKET CAPS through ADAPTER FOOT into CAGE ASSEMBLY, COLLAR may need to be rotated for screws to mount properly



 With ADAPTER in place re-secure CAGE ASSEMBLY to CAMERA by tightening SOCKET CAPS with 3/16 allen wrench





NOTE: To remove ADAPTER, remove M4x20 SOCKET CAPS from ADAPTER FOOT, push down on release button, and rotate counterclockwise.