

# WV-ASC970 IP Matrix Client Software WV-ASM970



# Easy and smooth integration from analog to IP system

### **Key Features: WV-ASC970**

- Flexible camera system: Analog, IP, and Hybrid analog/IP
- Up to 64 recorders, 64 decoders, and 2,048 cameras (in case with encoder) can be registered.
- Displays live images by selecting the camera number
- Controls camera and camera preset, and Group Preset
- Displays live Tour Sequence images on a multi-screen segment display
- Displays live Group Sequence images on several multi-screen segment displays
- Controls the camera selected by setting the users' priority in advance
- Selects the monitor selected by setting the users' priority in advance
- ON/OFF mode of the OSD on the selected monitor is possible.
- Sequence control: Tour Sequence (128 programs, 64 steps), Group Preset (128 programs, 64 views), Group Sequence (128 programs, 64 steps)
- Panasonic camera control: Pan/Tilt, Zoom, Focus, Brightness, Preset position call and program (up to 256), Auto mode (SEQ, SORT, AUTO PAN, PATROL), AUX 1 ~ 2
- · Controls wall monitors (Partially limited)
- Up to 512 users can be registered.
- Up to 64 users can login to WV-ASC970 simultaneously.
- Panasonic Alarm control by recorder, camera, and encoder
- Up to 1,024 alarms can be made.
- User management: User authentication
- Camera/Sequence/Monitor selection, Camera control and Recorder control can be made with the optional system controller WV-CU950.
- Individual alarm reset and all alarm reset is possible with the system controller WV-CU950 and WV-ASM970.

#### **Key Features: WV-ASM970**


- Multi-Monitor option enables simultaneous use of Operation screen and Monitor screen (1/4/7/9/10/13/16 split) on a dedicated monitor. Two monitor operation is also available.
- Up to 30 ips/camera can be displayed in 16 split-screen in MPEG-4 2 Mbps mode (depending on the camera, camera setup and PC performance).
- Up to 30 ips/camera can be displayed in 16 split-screen in H.264 1.5 Mbps mode with VGA (depending on the camera, camera setup and PC performance).

- Image resolution dynamically changes depending on the screen mode: VGA for Quad screen, QVGA for 16 split-screen, enabling optimum network usage (depending on the camera mode).
- When an alarm occurs, the monitor changes into the map automatically showing where the alarm happened.
- Up to 64 camera icons can be freely positioned on a map with alarm status indicated by the color of the icons.
- Please install WV-ASM970 on your server and download to each client PC via browser.

#### **System Components**



#### **Basic System Connection Example**



# Specifications: WV-ASC970

fications: WV	D
Supported Cameras	Panasonic Analog cameras,
Í	Panasonic i-Pro series Network cameras except WV-NM100,
	WV-NP472, WV-NS320 series, WV-NW470S series
Supported Recorders	WJ-ND400 series, WJ-ND300 series, WJ-ND200 series,
	WJ-HD300 series, WJ-HD300A series, WJ-RT416 series, WJ-HD716 series
	WJ-SX850, WJ-SX650EX
	WJ-NT304, WJ-NT314, WJ-GXE900 (MPEG-2 Encoder)*1
	WJ-GXD400, WJ-GXD900 (MPEG-2 Decoder)*1
- '	WV-CU950, WV-ASM970
•	
	2,048 (In case with encoder), Analog and/or IP camera*2
	-
	Pan/Tilt, Zoom, Focus, Brightness,
· ·	Preset position call and program (up to 256),
camera)	Auto mode (SEQ, SORT, AUTO PAN, PATROL),
	AUX 1 ~ 2
Recorder Control	REC (only Digital Disk Recorder), Playback
(depends on the recorder)	
Sequence Control	Tour Sequence: 128 programs, 64 steps
Í	Group Preset: 128 programs, 64 views
	Group Sequence: 128 programs, 64 steps
Camera Title Display	On the WJ-GXD400 and Analog Monitor
Alarm Source	Panasonic alarm protocol by Recorder, Camera, Encoder,
1	RS-232C I/O
Alarm Control	Reset, Auto reset, Arm, Disarm, Ack, Auto ack, All reset
Alarm Display Mode	Sequence, Hold
Alarm Action	Camera spot, Tour sequence, Group sequence
Max. Number of Alarm	1,024
System Log	Operation, Alarm, Switching, Video loss
User Management	Registration: Up to 512 users, ID: 5 digit, PW: 5 digit,
1	User level: customize
Simultaneous Login Users	Up to 64 (depends on network conditions)
Partitioning	Operator - Controller, Controller - Monitor,
1	Controller - Camera, Camera - Monitor
Security Method	User authentication, Controller authentication (MAC address)
Time Synchronization	NTP (Server/Client)
GUI (Admin) Language	English
Supported OS	Red Hat Enterprise Linux 5.3 server (x86)(English)
- '	
Required PC	CPU: Intel® Xeon® Processor 5140 (2.33 GHz) or faster.
Required PC	CPU: Intel® Xeon® Processor 5140 (2.33 GHz) or faster, RAM: 2 GB or more. Network: 2x 100/Gigabit or more.
Required PC	RAM: 2 GB or more, Network: 2x 100/Gigabit or more,
	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C
Required PC Supported OS	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoff® Windows® XP Professional SP3 (English and Chinese Version
	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoft® Windows® XP Professional SP3 (English and Chinese Version Microsoft® Windows Vista® Business 32-bit SP2 (English and Chinese Version
Supported OS	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoft® Windows® XP Professional SP3 (English and Chinese Version Microsoft® Windows Vista® Business 32-bit SP2 (English and Chinese Version Microsoft® Windows® 7 Professional 32-bit (English and Chinese Version
	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoft® Windows® XP Professional SP3 (English and Chinese Version Microsoft® Windows Vista® Business 32-bit SP2 (English and Chinese Version Microsoft® Windows® 7 Professional 32-bit (English and Chinese Version CPU: Intel® Pentium® 4 processor 3.0 GHz or faster
Supported OS	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoft® Windows® XP Professional SP3 (English and Chinese Version Microsoft® Windows Vista® Business 32-bit SP2 (English and Chinese Version Microsoft® Windows® 7 Professional 32-bit (English and Chinese Version CPU: Intel® Pentium® 4 processor 3.0 GHz or faster RAM: 512 MB or more
Supported OS	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoft® Windows® XP Professional SP3 (English and Chinese Version Microsoft® Windows® Vista® Business 32-bit SP2 (English and Chinese Version Microsoft® Windows® 7 Professional 32-bit (English and Chinese Version CPU: Intel® Pentium® 4 processor 3.0 GHz or faster RAM: 512 MB or more Network: 10/100 Mbps
Supported OS	RAM: 2 GB or more, Network: 2x 100/Gigabit or more, HDD: 80 GB or more free drive space, CD-ROM, Port: 1x RS-232C Microsoft® Windows® XP Professional SP3 (English and Chinese Version Microsoft® Windows Vista® Business 32-bit SP2 (English and Chinese Version Microsoft® Windows® 7 Professional 32-bit (English and Chinese Version CPU: Intel® Pentium® 4 processor 3.0 GHz or faster RAM: 512 MB or more
	Supported System Type Camera Control (depends on the camera) Recorder Control (depends on the recorder) Sequence Control  Camera Title Display Alarm Source  Alarm Control Alarm Display Mode Alarm Action Max. Number of Alarm System Log User Management  Simultaneous Login Users Partitioning Security Method Time Synchronization GUI (Admin) Language Supported OS

#### Specifications: WV-ASM970

•	ilcations. WV	
Supported	Supported Server	WV-ASC970*1
Equipment	Supported System Type	Multicast/Unicast system
GUI	Camera Control	Pan/Tilt, Zoom, Focus, Brightness, Preset position call
Function	(depends on the camera)	(up to 256), Auto Pan, AUX1-2
	Recorder Control	REC (only Digital Disk Recorder), Play, Rev Play, Pause, Stop,
	(depends on the recorder)	FF, REW, Prev Image, Next Image, Goto Last, Goto Date
	Wall Monitor Control	Display division pattern switch, Camera select switch,
		Tour sequence, Group preset, Group sequence, Monitor lock
	Event Search	Target: Recorder (Camera)
		Search criteria: Time date, Event type
	Multiscreen Mode	Spot / Quad (A-D) / 7 split / 9 split / 10 split / 13 split / 16 split
	Display Performance	30 ips x 16 screens at MPEG-4 2 Mbps*3
		30 ips x 16 screens at H.264 1.5 Mbps with VGA*3
	Multi-Monitor	2 Monitors (Operation/Monitor)
	Number of Maps	Up to 100 maps (JPEG or Bitmap), Link: 64 cameras/map
	Image Download	Recorded images of up to 64 (in case with WJ-ND400) can be
		downloaded. Manual download only. Viewer software can be
		extracted from the main software.
	Clock Display	On the GUI. Time: 12H/24H, Date: 5 formats
	Alarm Control	Reset, All reset, Arm, Disarm, Ack, Auto ack
	System Setup	Setup page in English, Chinese
	GUI Language	English, Chinese
PC	Supported OS	Microsoft® Windows® 7 Professional (32-bit) (English and Chinese Version)
Requirement		Microsoft® Windows® 7 Professional (64-bit)*2 (English and Chinese Version)
		Microsoft® Windows Vista® Business SP2 (32-bit) (English and Chinese Version)
		Microsoft® Windows Vista® Business SP2 (64-bit)*2 (English and Chinese Version)
		Microsoft® Windows® XP Professional SP3 (32-bit) (English and Chinese Version)
	Supported Browser	Microsoft® Internet Explorer® 6.0 Service Pack 3
		Microsoft® Internet Explorer® 7.0 Service Pack 1
		Microsoft® Internet Explorer® 8.0
	Required PC	CPU: Intel® Core™2 Duo 2.66 GHz or faster / Intel® Core™2
		Quad Q9650 or faster / Intel® Core™ i7-920 or faster,
		Memory: 2 GB or more / 3 GB or more (When operating H.264
		images),
		VRAM: 128 MB or more, compatible with DirectX® 9.0c
Network	Protocol	HTTP (IP address and port No.), FTP
Viewer	Playback Control	Play, Rev Play, Pause, FF, REW, Prev Record, Next Record,
Software		Prev Image, Next Image
	Additional Functions	Alteration detection, Save as JPEG, Two times zoom, Print


# \*1 NTSC only \*2 Depends on system configuration

## Flexible Alarm Action

Flexible alarm actions can be assigned for each alarm. Up to 1,024 alarms can be registered.

#### Alarm actions include:

- · Display alarm information on the designated monitor
- Display alarm images from the camera or start the sequence display on the designated monitor
- Turn on the alarm indicator on all the system controllers and WV-ASM970
- \* The WV-ASC970 does not support any error notifications (such as "REMOVE") from digital disk recorders or network disk recorders.



#### Trademarks and registered trademarks

- "Red Hat" is a trademark of Red Hat in the U.S. and other countries
- Intel, Xeon and Pentium are registered trademarks of Intel Corporation
- "Super Dynamic", "SDII", "SDIII" and "i-Pro" logos are trademarks or registered trademarks of Panasonic Corporation. Important
- Safety Precaution: carefully read the operating instructions and installation manual before using this product.
- Panasonic can not be responsible for network performance and/or other manufacturer products that reside on the network
- All TV pictures are simulated.
- Weights and dimensions are approximate.
- · Specifications are subject to change without notice.
- These products may be subject to export control regulations. • All product pictures are NTSC models.

#### **DISTRIBUTED BY:**



<sup>\*1</sup> WV-ASC970 Version 2.0 or later \*2 Operation in WOW64 (32-bit mode)
\*3 In case with Microsoft® Windows® 7 Professional (OS) and Intel® Core™ i7-920 (CPU)